

Laptop Handling and Care Instructions

Handle laptop with care

- Use the AC adapter whenever possible.
- Keep laptop in a safe place.
- Avoid exposure to extreme temperatures.
- Do not drop, bump or scratch laptop.
- Do not place heavy objects on your laptop.
- Avoid eating or drinking over laptop.
- Place laptop on solid surface, away from edge of table or desk.
- Avoid placing objects (including paper) between display and keyboard.
- Do not expose to dirty or dusty environments.

Carry laptop properly

- Turn off computer before moving it.
- Close display panel so that it is latched properly.
- Disconnect cords and cables.
- When lifting laptop, do not lift or hold by the display; hold it by the bottom.
- Always use carrying case.